Body Dimensional Drawings

Opening Repair Chart

Sedan:

unit: mm (in)

<Windshield/Door Opening>

Ⓐ
Dashboard upper cowl cover mounting hole



Ⓑ、Ⓒ
Windshield opening flange notch (3 places)



Ⓓ、Ⓔ、Ⓕ、Ⓖ、Ⓗ、Ⓘ、Ⓙ、Ⓚ
Door opening flange notch (4 places)





<Rear Window/Trunk Lid Opening>

Ⓛ、Ⓜ
Rear window opening flange notch (3 places)



Ⓝ
Trunk gutter area convex bead





Ⓞ
Outer panel flange end (2 places)



Ⓟ
Trunk seal flange water drain holes